

The C140 EPAS 15 unit offers the cinema Manager total emergency control, through the use of a single push button.

The unit operates by having the Projector Close Down system and the Emergency Evacuation system connected through its contactors.

Projection staff pressing the green push button, shown on the front of the unit initially sets the system.

When the Manager's remote button is pressed the cinema's projectors close down and the emergency evacuation systems engage: These typically would include curtains up, house lights on, fire brigade alert and the activation of evacuation voice chips.



